


## PROGRAMMER CONNECTOR (EEPROM)



## TOP VIEW OF THE CONNECTOR ON THE PROGRAMMER

0.1" PITCH 2\*5  
BOXHEADER WITH  
POLARISING NOTCH  
EEPROM PROGRAMMER

Programming signals for connector pins. For  
each eeprom family, as follows:

	24CXXX   25CXXX   93CXXX			
A	N/C	SI		DI
B	N/C	CS (bar)		CS
C	SCL	SCK		CLK
D	SDA	SO		DO

RESET: FOR  
CONNECTION TO  
MICROCONTROLLER  
RESET PIN, IF REQUIRED