

PROGRAMMER CONNECTOR (AVR)

GND	1	2	MISO
N/C	3	4	CLK
GND	5	6	RESET
GND	7	8	LED OPTIONAL
VCC	9	10	MOSI

TOP VIEW OF THE CONNECTOR ON
THE PROGRAMMER

0.1" PITCH 2*5 BOXHEADER
WITH POLARISING NOTCH